



Head Office: 30 Bay Street, Double Bay, NSW 2028 Australia Tel: 02 9328 5999 Int'l: +612 9328 5999 Fax: 02 9328 5699 Warehousing: Sydney Australia, Michigan USA, Slough UK

Wine Rack Assembly

The wine racks are assembled from these primary components:



Bottle Module AS200

Base Module AB200

Assembly Method:







