




SUPERLIFT

LOAD CAPACITY:
20 KG
(WITH POWER VARIATOR)




Aprire gli sportellini e fissare SUPERLIFT alla fiancata.

Open the doors and fasten SUPERLIFT to the side.

Die Türen öffnen und SUPERLIFT an der Seite befestigen.

Ouvrir les portes et fixer SUPERLIFT sur le côté.

Abrir las puertas y fijar SUPERLIFT en la parte lateral.




Svitare e raggiungere la posizione centrale dell'armadio.

Undo and access the centre of the wardrobe.

Losschrauben und die Schrankmitte erreichen.

Dévisser et atteindre la position centrale de l'armoire.

Destornillar y alcanzar la posición central del armario.



Fissare il tubo portagruccie e regola la potenza desiderata spostando la levetta posta sul retro.

Attach the hanger-support pipe and use the lever positioned at the back to regulate the required power.

Die Kleiderbügelstange befestigen und durch verschieben des Hebels an der Rückseite die Gewünschte Stärke einstellen.

Fixer la tube portécintres et régler la puissance voulue en déplaçant la manette placée à l'arrière.

Sujetar la barra porta perchas y regular la potencia deseada desplazando la palanca situada en la parte posterior.

WALLLIFT

LOAD CAPACITY:
10 KG

